

clicgear®

USER GUIDE
ユーザー・ガイド



MODEL

6+

※本書中、一部の画像について、商品と異なる部分がございます。



CLICGEAR OFFERS A WIDE SELECTION OF QUALITY GENUINE ACCESSORIES FOR THIS CART. PLEASE VISIT OUR WEBSITE OR ASK YOUR RETAILER FOR MORE INFORMATION. THANK YOU FOR BUYING A CLICGEAR CART!

www.clicgear.com

EN CONGRATULATIONS!

Every effort has been made to provide you with a unique and high quality product. Thank you for choosing the Clicgear Cart.

IMPORTANT

Before you start using your new Clicgear Cart, please read and understand the following important instructions and warnings contained in this user guide.

WARNING

- FOR YOUR OWN SAFETY, PLEASE READ AND UNDERSTAND THESE WARNINGS AND KEEP THIS USER GUIDE FOR FUTURE REFERENCE.
- This cart is not a toy and is designed for adult use only.
 - This cart is not intended for use as a baby stroller.
 - AVOID INJURY by always following the folding instructions carefully.
 - AVOID INJURY by keeping clear of moving parts while adjusting, folding or unfolding this cart.
 - ALWAYS make sure the cart is fully extended and locked before use.
 - ALWAYS make sure the cart is folded and locked properly before lifting or transporting.
 - ALWAYS use the brake when parking the cart and ensure it is adjusted properly.
 - DO NOT run while using this product.
 - DO NOT use accessories other than those designed for use with your Clicgear Cart.
 - KEEP all packing materials away from children and recycle where possible or where required by law.

Copyright © 2015 Clicgear Industries (Hong Kong) Ltd.
Clicgear is a Registered Trademark of Clicgear Industries Ltd.
All Designs are Patented or Patent Pending Status Worldwide.
Clicgear Reserves the Right to Make Changes to the Product.

JP お買い上げありがとうございます!

この度は、クリックギアカートをお買い上げいただき、ありがとうございます。弊社は、お客様にユニーク且つ高品質な製品を提供するため、あらゆる努力を行っています。

必ず、お読み下さい!


クリックギアカートをご使用の前に、本説明書をお読みいただき、使用方法や注意事項をご確認下さい。

使用上の注意

- 安全のため、以下の内容をご確認の上、ご使用下さい。
- 本品は、ゴルフプレー時の使用を前提に設計されています。お子様の遊具として使用しないで下さい。
 - 本品をベビーカー等として利用しないで下さい。
 - 展開・収納時は、説明書にしたがい、怪我をしないよう、注意して操作して下さい。
 - 怪我を避けるため、各可動部分が汚れた状態で調整、折りたたみや展開等の操作を行わないで下さい。
 - 本品が完全に展開され、ロックされた状態であることを確認した上で、ご利用下さい。
 - 本品が完全に折りたたまれ、ロックされた状態であることを確認した上で運搬・収納して下さい。
 - ブレーキが適切に動作するよう調整し、カートを停める際は必ずブレーキを使用して下さい。
 - カートを押しながら、走らないで下さい。
 - クリックギア・カート用に設計されたアクセサリ以外は使用しないで下さい。
 - 梱包材は自治体の指定する方式に従って処分し、お子様が梱包材で遊ばないように、ご注意下さい。

ASSEMBLY PART LIST /

内容品リスト



Part / 品番	Description / パーツ名	Qty / 数量	Part / 品番	Description / パーツ名	Qty / 数量
P1	Main Tube / メイン・チューブ	1	P9	Snap Pin / スナップ・ピン	4
P2	Axle Tube / アクセル・チューブ	1	P10	M6 x 43 mm Screw / ネジ	2
P3	Lower Saddle Assembly / ロワー・サドル・アッセンブリー	1	P11	M6 x 70 mm Screw / ネジ	1
P4	Upper Axle Support / アッパー・アクセル・サポート	1	P12	M6 x 126 mm Screw / ネジ	2
P5	Lower Bag Support Tube / ロワー・バッグ・サポート	1	P13	M6 Nylock Nut / M6 ナイロック・ナット	5
P6	Upper Saddle Assembly / アッパー・サドル・アッセンブリー	1	P14	Umbrella Tube / アンブレラ・チューブ	1
P7	Handle Assembly / ハンドル・アッセンブリー	1	P15	Cup Holder Plus / カップ・ホルダー	1
P8	Wheel Assembly / ホイール・アッセンブリー	2			